



Mueller
Human-Power

4893 Artino Ct. Eureka CA 95503 707-442-8133 mhp@Windwrap.com

Body Sock Accessories Instructions



Seat Hooks for Shell Seats:

Check seat hook for conformance in shape to the bottom of the seat shell and Clean bottom surface of shell seat with isopropyl alcohol. Remove backing tape from seat hook and place seat hook under seat. Use a spring clamp to hold seat hook snug against seat bottom for 24 or more hours.

Hook Side of Hook and Loop Tape:

Apply hook tape to edges of fairing as needed. Keep max length of tape strips under 10 inches. Thoroughly press the hook tape to fairing for best results.

Wait 24 hours before attaching the body sock to the hook tape. Do not leave the body sock attached to the fairing more than an hour when not riding.

Feel free to call if you have any questions: 877-267-1645 toll free in the US and Canada. 707-442-8133 all others.